

2018 ETCHELLS WORLDS & PRE WORLDS

HAUL IN & OUT INSTRUCTIONS

(1) SLEWING CRANE

IN

- BACKSTAYS OFF
- MAST CRANKED FORWARD
- BOW AND STERN LINES ON
- WAX & RAGS READY

(2) MOBILE CRANE

HAUL IN – Strops supplied by Brisbane Etchells or by Owners.

- Backstays off, bow lines on, hold down straps off before they get to the crane. Mast cranked forward
- 3 mins ONLY for keel pad wipe. All must be ready before they get to the crane
- 2 crew members must be on the dock to receive boat once it has been hauled from the trailer
- Tow vehicle and trailer to move out immediately the boat has been hauled

HAUL OUT – Strops supplied by Brisbane Etchells or by Owners

- Backstays off, mast cranked forward. Bow and stern lines on before boat gets to lift out position
- A crew member of the boat to be lifted must have the tow vehicle and trailer next in line before the haul out is attached No car trailer = no lift!!
- A crew member must be ready with ladder to detach once the boat hits the trailer.

Contact Information:

RQYS Main Number: 07 3396 8666 In case of an emergency for First Aid or Ambulance: DIAL 000

OUT

- BACKSTAYS OFF
- MAST CRANKED FORWARD
- BOW & STERN LINES ON
- CAR & TRAILER NOW!!
- NO CAR & TRAILER = NO LIFT!!